Understanding Regulated Medical Wastes:



Understanding Regulated Wastes

Simple solutions for managing your complex waste streams.



Regulated Medical Waste

Stericycle specializes in proper pickup, treatment, and disposal of RMW, such as "red bag" medical waste and sharps containers.

Safely dispose of:

Sharps

- Needles
- Glass items (pipettes, culture dishes, slides, etc.)
- Blades
- Soft ("Red Bag")
- · Bloody or saturated gauze, gloves, tubing
- Dressings



Pathological/Trace Chemo Waste

Secure pickup and incineration of all pathological items, including human* and animal tissue and/ or items with residual amounts of chemotherapy medications on them.

Take care of your wastes for incineration:

Pathological

- Limbs
- Organs Surgical specimens
- Other tissue
- Trace Chemo
- Gloves
- Masks
- Gowns Barriers
- IV tubing
- Empty Chemo vials • Empty Chemo
- IV bags

*Please refer to Stericycle's Waste Acceptance Policy regarding acceptable and unacceptable tissue.



Pharmaceutical Waste

Safe and simple disposal of hazardous and non-hazardous pharmaceutical wastes, with special subscription for controlled substances. Environmentally friendly solutions protect your communities, waterways and workplaces. Minimum effort, maximum impact.

Pharmaceutical waste is any pharmaceutical substance that can no longer be administered:

- Expired
- Partially administered
- Contaminated

Examples:

- Pills/capsules
- Ointments/creams
- Injectables
- Drops

Elixirs

Containers may vary according to your state's regulations. Pharmaceutical containers vary depending on pharmaceutical type.

25+ Years' Experience

bs of Regulated + Waste Managed [1]

30M + Pharmaceutical Waste Safely Disposed [2]

99.5% On-time Service [3]

Liability Protection [4]

Date: 7/10/2024

Copyright © 2017 Stericycle, Inc. All Rights Reserved

STC_WASTESEGSQ_0117



Medical Waste Packing Procedures:

PACKAGING PROCEDURES

FOR MEDICAL WASTE DISPOSAL • Reusable Containers' and Corrugated Boxes

SET UP CORRUGATED BOXES:

- . Turn over and seal bottom flaps with tape · Auto-locking boxes, engage bottom flaps







- . Auto-locking boxes, engage top flaps

REUSABLE CONTAINERS:

- · Secure lid on container
- · Ensure all closure and/or locking mechanisms are engaged



- · Federal markings (see picture above)
- · Additional state and local regulations may apply
- · Apply bar code label where available
- * Instructions not applicable for reusable sharps containers.
- For large or bulk reusable containers (greater than 119 gailons), bag must meet and be marked per current ASTM requirements, limited to a maximum 46 gailons and 22 lbs.



STEP 2

All containers pictured here have a maximum weight limit of 50 pounds.

The information on the poster is based on current federal laws and regulations. Additional state specific regulations may apply. Please be advised that regulations are subject to change.

REGULATORY REQUIREMENTS

GENERAL

- · Generators are responsible for packaging their wastes.
- · Each bag must be hand tied by gathering and twisting the neck of the bag and using a tie or hand knot to secure the bag, and each container must be securely closed.
- · Closed bags must not be visible once secondary container is closed.
- Improperly packaged containers or damaged containers will be denied pick-up or returned
- . Only Regulated Medical Waste can be placed in Stericycle containers.

SHARPS

- . Sharp materials ("sharps") must be placed in a puncture-resistant container designed for "sharps" waste. "Sharps" include needles, syringes, broken glass, scalpels, culture slides, culture dishes, broken capillary tubes, broken rigid plastic and exposed ends of dental wires.
- · All sharps containers should be properly closed before being placed into secondary containers.
- · No loose sharps are permitted outside of sharps containers.

For more information, contact Stericycle at (866) 783-7422.



ografică 2013 Switsyla, înc Allindra resnet

Date: 7/10/2024

Continued on Next Page...



Regulated Medical Waste Segregation Instructions:



(866) 783-7422 www.Sterlcycle.com

REGULATED MEDICAL WASTE

These **DO** go in the red bag:

Contaminated:

- Visibly Bloody Gloves
- Visibly Bloody Plastic Tubing
- Visibly Contaminated PPE
- Saturated Gauze

- Saturated Bandages
- Blood Saturated Items
- Closed Disposable
 Sharps Containers

Special handling and marking may be required for:

Certain Pathological Waste*

Trace-Chemotherapy*

These **DON'T** go in the red bag:



Medication*



Garbage



Loose Sharps



Fluorescein



Cauterizers



Batteries of Any Type



Hazardous and Chemical Waste



Compressed Gas Cylinders



Fixatives and Preservatives

check with your local state regulations



Radioactive Waste

Date: 7/10/2024

This document has been provided for the exclusive use by Stefcycle and Storicycle customers. It is the intellectual property of Storicycle, Inc. and should not be reproduced without the express written consent from Stericycle, Inc.

TO SURDENG (DIG SOURCE

Continued on Next Page...



Instructions for Determining What Items are Approved for Adding to Sharps Containers (AND What Items are NOT OK to Add):

To schedule a pickup, log in to MyStericycle.com or call 866-783-7422.



Regulated Medical Waste SHARPS CONTAINERS



PUT THESE IN THE SHARPS CONTAINER

Acupuncture Needles

Blood Vials

Broken Glass or Capillary Tubes

Culture Dishes and Slides

Exposed Ends of Dental Wires

Lancets

Needles, Hypodermic and Tubing

Pipettes

Root Canal Files

Scalpel Blades

Suture Needles

Syringes With and Without Needles

Trauma Scene Waste that can Cut. Slice or Pierce

Tubing With Needles







Medication'



Aerosols



Batterles of



Liquids



Hazardous and Chemical Waste



Fixatives and Preservatives





Medication Wrappers



Cauterizers



Fluorescein



Radioactive



Red Bag Waste

Order more sharps containers, red bags, liners, and waste supplies at MyStericycle.com.

This document has been provided for the exclusive use by Stedgycle and Sterloycle customers. It is the intellectual property of Sterloycle, inc. and should not be reproduced without the express written consent from Sterloycle, inc. Copyright © 2016 Switzyck, Inc. All Alights Reserved.

Date: 7/10/2024