The following Formaldehyde samples were collected from JFK on 01/04/2019 from the listed areas:

M23

M04E

M04D

U02A





Air Analysis For: JFK Shipping EWU EH2S

Location Tested: 002 Martin Hall Cheney, WA 99004

Sampling Professional: Donald Johnson

Eastern Washington University

319 Showalter Hall Cheney, WA 99004

Client Sample ID: M23

Sample Volume (L): 4.0

Date Sampled: 01/04/2019 Sample Type: TDT ZZ325 Sample Condition: Acceptable

Report Number: 76081 Laboratory ID: 76081-1

> Thank you for using IAQ Commercial Survey!

If you have questions about your report, please contact your service provider who

performed this test.

Order Date: 01/08/2019 Scan Date: 01/09/2019 Report Date: 01/10/2019

Formaldehyde Concentration: < 15' ng/L

Your Formaldehyde Level (Highlighted)



Moderate

Elevated


High

20-50 ng/L 16-40 ppb

50-100 ng/L > 100 ng/L 40-80 ppb > 80 ppb

Recommendation: No significant formaldehyde issues.

All IAQ Survey Formaldehyde Results



This chart represents the Formaldehyde distribution of over 7,000 samples.

Approximately half the samples have concentrations in the 30-70 ng/L range.

The chart above shows the formaldehyde concentrations for all locations tested using IAQ Survey. Results for this air sample are displayed on the chart as a yellow circle. The blue curved line represents the relationship between the percentage of locations (indicated on the vertical y-axis) and the formaldehyde concentration (indicated on the horizontal x-axis). The green, yellow, orange, and red vertical bars represent divisions between Low, Moderate, Elevated, and High formaldehyde concentrations.









The US Occupational Safety and Health Administration (OSHA) has set a workplace **permissible exposure limit** (PEL) of 940 ng/L (750 parts per billion). The National Institute for Occupational Safety and Health (NIOSH) has set a **recommended exposure limit** (REL) of 20 ng/L (16 ppb) with a 120 ng/L (100 ppb) 15 minute ceiling limit.

Although these formaldehyde concentration limits are applicable to all types of workplace environments, most office or retail locations without additional occupational exposure (e.g., industrial or manufacturing processes generating formaldehyde) typically have formaldehyde concentrations less than 100 ng/L (80 ppb). Most indoor environments measured by Prism's air test have concentrations in the range of 30 to 70 ng/L.

The table below provides some of the limits applicable to workplace environments. In general, formaldehyde concentrations should be kept as low as reasonably achievable.

| Organization | Concentration | | Туре |
|--------------|---------------------|---------------------|--|
| | ng/L | ppb | |
| OSHA | 630 940 2,500 | 500 750 2,000 | Action Level (8 hour) PEL (8 hour) STEL (15 min) |
| NIOSH | 20 120 | 16 100 | REL (8 hour) Ceiling (15 min) |
| ACGIH | 370 | 300 | TLV (8 hour) |
| LEED | 32 | 27 | Green Building (4 hour) |
| WHO | 100 | 80 | Short-Term (0.5 hour) |
| | | | |

OSHA: Occupational Health and Safety Administration

NIOSH: National Institute for Occupational Safety and Health

ACGIH: American Conference of Governmental Industrial Hygienists

LEED: Leadership in Energy & Environmental Design (Green Building Council)

WHO: World Health Organization

PEL: Permissible Exposure Limit

REL: Recommended Exposure Limit

TLV: Threshold Limit Value

TWA: Time Weighted Average

STEL: Short Term Exposure Limit

Note: Concentration can be expressed in several ways and various organizations may use different units.

 $1 \text{ ng/L} = 1 \mu\text{g/m}^3 = 0.001 \text{ mg/m}^3$

1 ppb = 0.001 ppm

To convert between the two sets of units listed above the molecular weight of formaldehyde must be used, which produces the conversion factors below:

ppb concentration = ng/L concentration * 0.8 or ng/L concentration= ppb concentration * 1.25

Major Health Effects of Formaldehyde Exposure





There are many possible sources for formaldehyde in the indoor environment, although building products typically make up a large proportion of the concentration. Any recent renovation or new material brought into the building is likely to increase the formaldehyde levels. The concentration will decrease over time as the materials off gas, so increasing the ventilation as much as possible is typically the best way to quickly decrease formaldehyde after recent renovation or installation of new materials.

- Products that contain urea-formaldehyde (UF) resins
 - particleboard, hardwood plywood paneling, medium density fiberboard
- Products that contain phenol-formaldehyde (PF) resins (lower concentrations of formaldehyde than UF resins)
 - softwood plywood, flake or oriented strand board
- Pre-finished engineered flooring
- Insulation
- Glues and adhesives
- Paints and coatings
- Textiles
- Disinfectant cleaning products and soaps
- Preservatives
- Personal care products, especially certain hair products
- Cosmetics
- Pet care products
- Bactericides and fungicides
- Combustion byproduct (burning)
 - Tobacco smoke and fuel-burning appliances (gas stoves, kerosene space heaters and fireplaces)

Formaldehyde is also produced naturally in living systems, e.g., trees and other plant life, and during decay and combustion processes. Formaldehyde is also involved in atmospheric processes. Outdoor concentrations of formaldehyde from both natural and man-made sources can range from less than 1 ng/L in remote areas to 10-20 ng/L in urban environments.

Additional Resources

US OSHA Toxic and Hazardous Substances-Formaldehyde

US OSHA Fact Sheet-Formaldehyde

US NIOSH Formaldehyde

World Health Organization (WHO) Air Quality Guidelines for Europe, 2nd Edition (2000); pg 87-91

Europe: Report No. 7-Indoor Air Pollution by Formaldehyde in European Countries (1990)

US Consumer Product Safety Commission (CPSC) Update on Formaldehyde (2013)

US Environmental Protection Agency: Formaldehyde

US Agency for Toxic Substances and Disease Registry (ATSDR): Formaldehyde ToxFAQsTM

US National Institutes of Health (NIH): ToxTown: Formaldehyde

Chemical Reviews (Journal): Formaldehyde in the Indoor Environment

Household Products Database: Formaldehyde

These results are authorized by the Laboratory Director or approved representative.

This analysis was performed by Prism Analytical Technologies, Inc. (Prism) using the Hantzsch, or acetylacetone (acac), method. This test method has been correlated with or is compliant with the California Air Resources Board (CARB) § 93120, European DIN Standard EN-717, and ASTM methods D-5582 and E-1333. It has also been compared with DNPH testing used in NIOSH 2016 and found to be in good agreement.

The results contained in this report are dependent upon a number of factors over which Prism has no control, which may include, but are not limited to, the sampling technique utilized, the size or source of sample, and the ability of the sampler to collect a proper or suitable sample. Therefore, the opinions contained in this report may be invalid and cannot be considered or construed as definitive and neither Prism, nor its agents, officers, directors, employees, or successors shall be liable for any claims, actions, causes of action, costs, loss of service, medical or other expenses or any compensation whatsoever which may now or hereafter occur or accrue based upon the information or opinions contained herein.





Air Analysis For: JFK Shipping EWU EH2S

Location Tested: 002 Martin Hall Cheney, WA 99004

Sampling Professional: Donald Johnson

Eastern Washington University

319 Showalter Hall Cheney, WA 99004

Client Sample ID: M04E Sample Volume (L): 4.0

Date Sampled: 01/04/2019 Sample Type: TDT AD217 Sample Condition: Acceptable

Report Number: 76081 Laboratory ID: 76081-3

> Thank you for using IAQ Commercial Survey!

If you have questions about your report, please contact your service provider who

performed this test.

Order Date: 01/08/2019 Scan Date: 01/09/2019 Report Date: 01/10/2019

Formaldehyde Concentration: < 15 ng/L (< 12 ppb)

Your Formaldehyde Level (Highlighted)

Moderate

20-50 ng/L 16-40 ppb


Elevated

50-100 ng/L > 100 ng/L 40-80 ppb > 80 ppb

High

Recommendation: No significant formaldehyde issues.

All IAQ Survey Formaldehyde Results



This chart represents the Formaldehyde distribution of over 7,000 samples.

Approximately half the samples have concentrations in the 30-70 ng/L range.

The chart above shows the formaldehyde concentrations for all locations tested using IAQ Survey. Results for this air sample are displayed on the chart as a yellow circle. The blue curved line represents the relationship between the percentage of locations (indicated on the vertical y-axis) and the formaldehyde concentration (indicated on the horizontal x-axis). The green, yellow, orange, and red vertical bars represent divisions between Low, Moderate, Elevated, and High formaldehyde concentrations.









The US Occupational Safety and Health Administration (OSHA) has set a workplace **permissible exposure limit** (PEL) of 940 ng/L (750 parts per billion). The National Institute for Occupational Safety and Health (NIOSH) has set a **recommended exposure limit** (REL) of 20 ng/L (16 ppb) with a 120 ng/L (100 ppb) 15 minute ceiling limit.

Although these formaldehyde concentration limits are applicable to all types of workplace environments, most office or retail locations without additional occupational exposure (e.g., industrial or manufacturing processes generating formaldehyde) typically have formaldehyde concentrations less than 100 ng/L (80 ppb). Most indoor environments measured by Prism's air test have concentrations in the range of 30 to 70 ng/L.

The table below provides some of the limits applicable to workplace environments. In general, formaldehyde concentrations should be kept as low as reasonably achievable.

| Organization | Concentration | | Туре |
|--------------|---------------------|---------------------|--|
| | ng/L | ppb | |
| OSHA | 630 940 2,500 | 500 750 2,000 | Action Level (8 hour) PEL (8 hour) STEL (15 min) |
| NIOSH | 20 120 | 16 100 | REL (8 hour) Ceiling (15 min) |
| ACGIH | 370 | 300 | TLV (8 hour) |
| LEED | 32 | 27 | Green Building (4 hour) |
| WHO | 100 | 80 | Short-Term (0.5 hour) |
| | | | |

OSHA: Occupational Health and Safety Administration

NIOSH: National Institute for Occupational Safety and Health

ACGIH: American Conference of Governmental Industrial Hygienists

LEED: Leadership in Energy & Environmental Design (Green Building Council)

WHO: World Health Organization

PEL: Permissible Exposure Limit REL: Recommended Exposure Limit

TLV: Threshold Limit Value

TWA: Time Weighted Average STEL: Short Term Exposure Limit

Note: Concentration can be expressed in several ways and various organizations may use different units.

 $1 \text{ ng/L} = 1 \mu\text{g/m}^3 = 0.001 \text{ mg/m}^3$

1 ppb = 0.001 ppm

To convert between the two sets of units listed above the molecular weight of formaldehyde must be used, which produces the conversion factors below:

ppb concentration = ng/L concentration * 0.8 or ng/L concentration= ppb concentration * 1.25

Major Health Effects of Formaldehyde Exposure





There are many possible sources for formaldehyde in the indoor environment, although building products typically make up a large proportion of the concentration. Any recent renovation or new material brought into the building is likely to increase the formaldehyde levels. The concentration will decrease over time as the materials off gas, so increasing the ventilation as much as possible is typically the best way to quickly decrease formaldehyde after recent renovation or installation of new materials.

- Products that contain urea-formaldehyde (UF) resins
 - particleboard, hardwood plywood paneling, medium density fiberboard
- Products that contain phenol-formaldehyde (PF) resins (lower concentrations of formaldehyde than UF resins)
 - · softwood plywood, flake or oriented strand board
- Pre-finished engineered flooring
- Insulation
- Glues and adhesives
- Paints and coatings
- Textiles
- Disinfectant cleaning products and soaps
- Preservatives
- Personal care products, especially certain hair products
- Cosmetics
- Pet care products
- Bactericides and fungicides
- Combustion byproduct (burning)
 - Tobacco smoke and fuel-burning appliances (gas stoves, kerosene space heaters and fireplaces)

Formaldehyde is also produced naturally in living systems, e.g., trees and other plant life, and during decay and combustion processes. Formaldehyde is also involved in atmospheric processes. Outdoor concentrations of formaldehyde from both natural and man-made sources can range from less than 1 ng/L in remote areas to 10-20 ng/L in urban environments.

Additional Resources

US OSHA Toxic and Hazardous Substances-Formaldehyde

US OSHA Fact Sheet-Formaldehyde

US NIOSH Formaldehyde

World Health Organization (WHO) Air Quality Guidelines for Europe, 2nd Edition (2000); pg 87-91

Europe: Report No. 7-Indoor Air Pollution by Formaldehyde in European Countries (1990)

US Consumer Product Safety Commission (CPSC) Update on Formaldehyde (2013)

US Environmental Protection Agency: Formaldehyde

US Agency for Toxic Substances and Disease Registry (ATSDR): Formaldehyde ToxFAQs™

US National Institutes of Health (NIH): ToxTown: Formaldehyde

Chemical Reviews (Journal): Formaldehyde in the Indoor Environment

Household Products Database: Formaldehyde

These results are authorized by the Laboratory Director or approved representative.

This analysis was performed by Prism Analytical Technologies, Inc. (Prism) using the Hantzsch, or acetylacetone (acac), method. This test method has been correlated with or is compliant with the California Air Resources Board (CARB) § 93120, European DIN Standard EN-717, and ASTM methods D-5582 and E-1333. It has also been compared with DNPH testing used in NIOSH 2016 and found to be in good agreement.

Canina Air resortes because (or resorted to a control of the contr



A Q Commercial Survey™ Formaldehyde

Air Analysis For: JFK Shipping EWU EH2S

Location Tested: 002 Martin Hall Cheney, WA 99004

Sampling Professional: Donald Johnson

Eastern Washington University

319 Showalter Hall Cheney, WA 99004

Client Sample ID: M04D Sample Volume (L): 4.0

Date Sampled: 01/04/2019 Sample Type: TDT RR203 Sample Condition: Acceptable

Report Number: 76081 Laboratory ID: 76081-2

> Thank you for using IAQ Commercial Survey!

If you have questions about your report, please contact your service provider who

performed this test.

Order Date: 01/08/2019 Scan Date: 01/09/2019 Report Date: 01/10/2019

Formaldehyde Concentration: 18 ng/L (15 ppb)

Your Formaldehyde Level (Highlighted)


Moderate 20-50 ng/L

16-40 ppb 40-80 ppb

Elevated High 50-100 ng/L > 100 ng/L > 80 ppb

Recommendation: No significant formaldehyde issues.

All IAQ Survey Formaldehyde Results



This chart represents the Formaldehyde distribution of over 7,000 samples.

Approximately half the samples have concentrations in the 30-70 ng/L range.

The chart above shows the formaldehyde concentrations for all locations tested using IAQ Survey. Results for this air sample are displayed on the chart as a yellow circle. The blue curved line represents the relationship between the percentage of locations (indicated on the vertical y-axis) and the formaldehyde concentration (indicated on the horizontal x-axis). The green, yellow, orange, and red vertical bars represent divisions between Low, Moderate, Elevated, and High formaldehyde concentrations.





Page 2 of 4





The US Occupational Safety and Health Administration (OSHA) has set a workplace **permissible exposure limit** (PEL) of 940 ng/L (750 parts per billion). The National Institute for Occupational Safety and Health (NIOSH) has set a **recommended exposure limit** (REL) of 20 ng/L (16 ppb) with a 120 ng/L (100 ppb) 15 minute ceiling limit.

Although these formaldehyde concentration limits are applicable to all types of workplace environments, most office or retail locations without additional occupational exposure (e.g., industrial or manufacturing processes generating formaldehyde) typically have formaldehyde concentrations less than 100 ng/L (80 ppb). Most indoor environments measured by Prism's air test have concentrations in the range of 30 to 70 ng/L.

The table below provides some of the limits applicable to workplace environments. In general, formaldehyde concentrations should be kept as low as reasonably achievable.

| Organization | Concentration | | Type |
|--------------|---------------------|---------------------|--|
| | ng/L | ppb | |
| OSHA | 630 940 2,500 | 500 750 2,000 | Action Level (8 hour) PEL (8 hour) STEL (15 min) |
| NIOSH | 20 120 | 16 100 | REL (8 hour) Ceiling (15 min) |
| ACGIH | 370 | 300 | TLV (8 hour) |
| LEED | 32 | 27 | Green Building (4 hour) |
| WHO | 100 | 80 | Short-Term (0.5 hour) |

OSHA: Occupational Health and Safety Administration

NIOSH: National Institute for Occupational Safety and Health

ACGIH: American Conference of Governmental Industrial Hygienists

LEED: Leadership in Energy & Environmental Design (Green Building Council)

WHO: World Health Organization

PEL: Permissible Exposure Limit

REL: Recommended Exposure Limit

TLV: Threshold Limit Value

TWA: Time Weighted Average

STEL: Short Term Exposure Limit

Note: Concentration can be expressed in several ways and various organizations may use different units.

 $1 \text{ ng/L} = 1 \mu\text{g/m}^3 = 0.001 \text{ mg/m}^3$

1 ppb = 0.001 ppm

To convert between the two sets of units listed above the molecular weight of formaldehyde must be used, which produces the conversion factors below:

ppb concentration = ng/L concentration * 0.8 or ng/L concentration= ppb concentration * 1.25

Major Health Effects of Formaldehyde Exposure





There are many possible sources for formaldehyde in the indoor environment, although building products typically make up a large proportion of the concentration. Any recent renovation or new material brought into the building is likely to increase the formaldehyde levels. The concentration will decrease over time as the materials off gas, so increasing the ventilation as much as possible is typically the best way to quickly decrease formaldehyde after recent renovation or installation of new materials.

- Products that contain urea-formaldehyde (UF) resins
 - particleboard, hardwood plywood paneling, medium density fiberboard
- Products that contain phenol-formaldehyde (PF) resins (lower concentrations of formaldehyde than UF resins)
 - softwood plywood, flake or oriented strand board
- Pre-finished engineered flooring
- Insulation
- Glues and adhesives
- Paints and coatings
- Textiles
- Disinfectant cleaning products and soaps
- Preservatives
- Personal care products, especially certain hair products
- Cosmetics
- Pet care products
- Bactericides and fungicides
- Combustion byproduct (burning)
 - Tobacco smoke and fuel-burning appliances (gas stoves, kerosene space heaters and fireplaces)

Formaldehyde is also produced naturally in living systems, e.g., trees and other plant life, and during decay and combustion processes. Formaldehyde is also involved in atmospheric processes. Outdoor concentrations of formaldehyde from both natural and man-made sources can range from less than 1 ng/L in remote areas to 10-20 ng/L in urban environments.

Additional Resources

US OSHA Toxic and Hazardous Substances-Formaldehyde

US OSHA Fact Sheet-Formaldehyde

US NIOSH Formaldehyde

World Health Organization (WHO) Air Quality Guidelines for Europe, 2nd Edition (2000); pg 87-91

Europe: Report No. 7-Indoor Air Pollution by Formaldehyde in European Countries (1990)

US Consumer Product Safety Commission (CPSC) Update on Formaldehyde (2013)

US Environmental Protection Agency: Formaldehyde

US Agency for Toxic Substances and Disease Registry (ATSDR): Formaldehyde ToxFAQs™

US National Institutes of Health (NIH): ToxTown: Formaldehyde

Chemical Reviews (Journal): Formaldehyde in the Indoor Environment

Household Products Database: Formaldehyde

These results are authorized by the Laboratory Director or approved representative.

This analysis was performed by Prism Analytical Technologies, Inc. (Prism) using the Hantzsch, or acetylacetone (acac), method. This test method has been correlated with or is compliant with the California Air Resources Board (CARB) § 93120, European DIN Standard EN-717, and ASTM methods D-5582 and E-1333. It has also been compared with DNPH testing used in NIOSH 2016 and found to be in good agreement.

The results contained in this report are dependent upon a number of factors over which Prism has no control, which may include, but are not limited to, the sampling technique utilized, the size or source of sample, and the ability of the sampler to collect a proper or suitable sample. Therefore, the opinions contained in this report may be invalid and cannot be considered or construed as definitive and neither Prism, nor its agents, officers, directors, employees, or successors shall be liable for any claims, actions, causes of action, costs, loss of service, medical or other expenses or any compensation whatsoever which may now or hereafter occur or accrue based upon the information or opinions contained herein.





Air Analysis For: JFK Shipping EWU EH2S

Location Tested: 002 Martin Hall Cheney, WA 99004

Sampling Professional: Donald Johnson

Eastern Washington University

319 Showalter Hall Cheney, WA 99004

Client Sample ID: U02A Sample Volume (L): 4.0

Date Sampled: 01/04/2019 Sample Type: TDT ZZ324 Sample Condition: Acceptable

Report Number: 76081 Laboratory ID: 76081-4

> Thank you for using IAQ Commercial Survey!

If you have questions about your report, please contact your service provider who performed this test.

Order Date: 01/08/2019 Scan Date: 01/09/2019 Report Date: 01/10/2019

Formaldehyde Concentration: 16 ng/L (13 ppb)

Your Formaldehyde Level (Highlighted)

Moderate


Elevated 20-50 ng/L 16-40 ppb 40-80 ppb

High 50-100 ng/L > 100 ng/L

> 80 ppb

Recommendation: No significant formaldehyde issues.

All IAQ Survey Formaldehyde Results



This chart represents the Formaldehyde distribution of over 7,000 samples.

Approximately half the samples have concentrations in the 30-70 ng/L range.

The chart above shows the formaldehyde concentrations for all locations tested using IAQ Survey. Results for this air sample are displayed on the chart as a yellow circle. The blue curved line represents the relationship between the percentage of locations (indicated on the vertical y-axis) and the formaldehyde concentration (indicated on the horizontal x-axis). The green, yellow, orange, and red vertical bars represent divisions between Low, Moderate, Elevated, and High formaldehyde concentrations.









The US Occupational Safety and Health Administration (OSHA) has set a workplace **permissible exposure limit** (PEL) of 940 ng/L (750 parts per billion). The National Institute for Occupational Safety and Health (NIOSH) has set a **recommended exposure limit** (REL) of 20 ng/L (16 ppb) with a 120 ng/L (100 ppb) 15 minute ceiling limit.

Although these formaldehyde concentration limits are applicable to all types of workplace environments, most office or retail locations without additional occupational exposure (e.g., industrial or manufacturing processes generating formaldehyde) typically have formaldehyde concentrations less than 100 ng/L (80 ppb). Most indoor environments measured by Prism's air test have concentrations in the range of 30 to 70 ng/L.

The table below provides some of the limits applicable to workplace environments. In general, formaldehyde concentrations should be kept as low as reasonably achievable.

| Organization | Concentration | | Туре |
|--------------|---------------------|---------------------|--|
| | ng/L | ppb | |
| OSHA | 630 940 2,500 | 500 750 2,000 | Action Level (8 hour) PEL (8 hour) STEL (15 min) |
| NIOSH | 20 120 | 16 100 | REL (8 hour) Ceiling (15 min) |
| ACGIH | 370 | 300 | TLV (8 hour) |
| LEED | 32 | 27 | Green Building (4 hour) |
| WHO | 100 | 80 | Short-Term (0.5 hour) |

OSHA: Occupational Health and Safety Administration

NIOSH: National Institute for Occupational Safety and Health

ACGIH: American Conference of Governmental Industrial Hygienists

LEED: Leadership in Energy & Environmental Design (Green Building Council)

WHO: World Health Organization

PEL: Permissible Exposure Limit REL: Recommended Exposure Limit

TLV: Threshold Limit Value

TWA: Time Weighted Average

STEL: Short Term Exposure Limit

Note: Concentration can be expressed in several ways and various organizations may use different units.

 $1 \text{ ng/L} = 1 \mu\text{g/m}^3 = 0.001 \text{ mg/m}^3$

1 ppb = 0.001 ppm

To convert between the two sets of units listed above the molecular weight of formaldehyde must be used, which produces the conversion factors below:

ppb concentration = ng/L concentration * 0.8 or ng/L concentration= ppb concentration * 1.25

Major Health Effects of Formaldehyde Exposure





There are many possible sources for formaldehyde in the indoor environment, although building products typically make up a large proportion of the concentration. Any recent renovation or new material brought into the building is likely to increase the formaldehyde levels. The concentration will decrease over time as the materials off gas, so increasing the ventilation as much as possible is typically the best way to quickly decrease formaldehyde after recent renovation or installation of new materials.

- · Products that contain urea-formaldehyde (UF) resins
 - particleboard, hardwood plywood paneling, medium density fiberboard
- Products that contain phenol-formaldehyde (PF) resins (lower concentrations of formaldehyde than UF resins)
 - softwood plywood, flake or oriented strand board
- Pre-finished engineered flooring
- Insulation
- Glues and adhesives
- Paints and coatings
- a Taytilas
- · Disinfectant cleaning products and soaps
- Preservatives
- Personal care products, especially certain hair products
- Cosmetics
- Pet care products
- Bactericides and fungicides
- Combustion byproduct (burning)
 - Tobacco smoke and fuel-burning appliances (gas stoves, kerosene space heaters and fireplaces)

Formaldehyde is also produced naturally in living systems, e.g., trees and other plant life, and during decay and combustion processes. Formaldehyde is also involved in atmospheric processes. Outdoor concentrations of formaldehyde from both natural and man-made sources can range from less than 1 ng/L in remote areas to 10-20 ng/L in urban environments.

Additional Resources

US OSHA Toxic and Hazardous Substances-Formaldehyde

US OSHA Fact Sheet-Formaldehyde

US NIOSH Formaldehyde

World Health Organization (WHO) Air Quality Guidelines for Europe, 2nd Edition (2000): pg 87-91

Europe: Report No. 7-Indoor Air Pollution by Formaldehyde in European Countries (1990)

US Consumer Product Safety Commission (CPSC) Update on Formaldehyde (2013)

US Environmental Protection Agency: Formaldehyde

US Agency for Toxic Substances and Disease Registry (ATSDR): Formaldehyde ToxFAQs™

US National Institutes of Health (NIH): ToxTown: Formaldehyde

Chemical Reviews (Journal): Formaldehyde in the Indoor Environment

Household Products Database: Formaldehyde

These results are authorized by the Laboratory Director or approved representative.

This analysis was performed by Prism Analytical Technologies, Inc. (Prism) using the Hantzsch, or acetylacetone (acac), method. This test method has been correlated with or is compliant with the California Air Resources Board (CARB) § 93120, European DIN Standard EN-717, and ASTM methods D-5582 and E-1333. It has also been compared with DNPH testing used in NIOSH 2016 and found to be in good agreement.

tound to be in good agreement.
The results contained in this report are dependent upon a number of factors over which Prism has no control, which may include, but are not limited to, the sampling technique utilized, the size or source of sample, and the ability of the sampler to collect a proper or suitable sample. Therefore, the opinions contained in this report may be invalid and cannot be considered or construed as definitive and neither Prism, nor its agents, officers, directors, employees, or successors shall be liable for any claims, actions, causes of action, costs, loss of service, medical or other expenses or any compensation whatsoever which may now or hereafter occur or accrue based upon the information or opinions contained herein.